



\*\*NOTE: P1-P4 are PCM Pins for BR-LE4.0-D2A ONLY, Do not add pads if using another module

\*\*NOTE: J1-J4 are Programming Pins for BR-LE4.0-D2A ONLY, Do not add pads if using another module



BR-LE4.0-S2A BR-C46AR  
 BR-LE4.0-S3A WML-C46AHR  
 BR-LE4.0-D2A Recommended Footprint

BlueRadios, Inc

Size	FCSM No.	DWG No.	Rev
Tabloid			B
Scale		Sheet	1 of 1